

TRUCHECK™ 2

QUICK REFERENCE GUIDE



OPERATOR'S MANUAL

www.norbar.com/Downloads/Manuals

Part Number	43514 / 5	43516 / 7	43518 / 9	43520 / 1	43522 / 3	43524 / 5	43528 / 9	43530 / 1	43532 / 3
Capacity	3 N·m	10 N·m	30 N·m	65 N·m	260 lbf·ft	350 N·m	800 lbf·ft	1,100 N·m	2,100 N·m
Max Torque	3.6 N·m	12 N·m	36 N·m	78 N·m	312 lbf·ft	420 N·m	960 lbf·ft	1,320 N·m	2,310 N·m

<p>PRESS Changes Units</p> <p>UNITS</p> <p>PRESS & HOLD Units Menu</p>	<p>PRESS Changes Mode</p> <p>MODE</p> <p>PRESS & HOLD Click Menu</p>	<p>PRESS Changes Target</p> <p>TARGET</p> <p>PRESS & HOLD Target Menu</p>	<p>PRESS Resets Peak or Zeroes Reading</p> <p>RESET</p> <p>PRESS & HOLD Version Screen</p>
---	---	--	---



<p>PRESS Zeroes Reading</p> <p>PRESS & HOLD Version Screen</p>	<p>RESET</p>	<p>TARGET</p>
<p>EXIT</p>	<p>TruCheck™ 2 Plus</p>	
<p>EXIT</p>	<p>5 Seconds</p> <p>SETUP MENU</p>	<p>TruCheck™ 2</p>

NORBAR TORQUE TOOLS LTD, Wildmere Road, Banbury, Oxfordshire, OX16 3JU, UNITED KINGDOM

Tel: + 44 (0) 1295 270333 | Email: enquiry@norbar.com

www.norbar.com

